

SEL-387-0, -5, -6 Connectorized®

Current Differential and Overcurrent Relay, Standard With 20 Outputs, 14 Inputs, Plug-In Connectors, and ACSELERATOR QuickSet® SEL-5030 Software⁽¹⁾

Part Number:

0	3	8	7				X										X	
---	---	---	---	--	--	--	---	--	--	--	--	--	--	--	--	--	---	--

Firmware

Standard						0												X
Standard plus Integration Enhancements With Binary SER						5												
Standard plus Integration Enhancements With Binary SER and Thermal Element*						6												

I/O Board; Chassis

20 Std Outputs, 14 Inputs, 3U (12 outputs are configurable, Form A or Form B)							Y										2			
8 Std Outputs, 12 High I/C Outputs, 14 Inputs, 3U (12 outputs are configurable, Form A or Form B)*							Y										6			

Power Supply

24/48 Vdc																	2			
48/125 Vdc or 125 Vac																	3			
125/250 Vdc or Vac																	4			

Secondary Input Current

1 A Phase																	1			
5 A Phase																	5			

Mounting

Horizontal Rack Mount																	H			
Horizontal Panel Mount																	3			
Horizontal Projection Panel Mount*																	5			

Conformal Coat

None																		X		
Conformally Coated Circuit Boards*																		2		

Control Input Voltage

24 Vdc																			1	
48 Vdc																			2	
110 Vdc																			3	
125 Vdc																			4	
250 Vdc																			6	

Communications Protocol

Standard - SEL ASCII, SEL Compressed ASCII, SEL Distributed Port Switch (LMD), Fast Meter and Fast Operate																				X
Standard plus DNP 3.00 Level 2 Slave (available only in 387-5, -6)*																				1

Accessories

Literature																				
	SEL-387-0, -5, -6 Printed English Instruction Manual ⁽²⁾	P	M	3	8	7	-	0	1											
	SEL-387-0, -5, -6 Printed Spanish Instruction Manual ⁽²⁾	P	M	3	8	7	-	0	7											

Wiring Harness		
	Wiring Harness for Connectorized SEL-387 ^{(3)*}	Please see Online MOT or contact SEL REP or CSR for ordering information.

*Additional Cost

⁽¹⁾ Download acSELERATOR QuickSet SEL-5030 software for free at <https://www.selinc.com/software/solutions/>. QuickSet on CD (503001WX4) is available upon request. QuickSet does not support the SEL-387-0.

⁽²⁾ The SEL-387-0, -5, -6 Connectorized[®] comes standard with a CD manual. One complimentary printed instruction manual is available upon request with each product purchased.

⁽³⁾ Order a Connectorized[®] Wiring Harness for SEL-387 (harness shipped separately).

Making Electric Power Safer, More Reliable, and More Economical[®]

SEL SCHWEITZER ENGINEERING LABORATORIES, INC.

2350 NE Hopkins Court - Pullman, WA 99163 USA
 Phone: +1.509.332.1890 - Fax: +1.509.332.7990