

STANDARD BLOCK CONFIGURATION TABLE

Note Current Channel Configurations

Pole #	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Configuration Number																				
SB01	V	V	V	V	S	S	T	X	X	X	X	X	X	X	X	X	X	X	X	X
SB02	V	V	V	V	S	S	S	S	S	S	S	S	S	T	X	X	X	X	X	X
SB03	C	C	C	C	C	C	S	S	S	S	S	S	S	T	X	X	X	X	X	X
SB04	C	C	C	C	S	S	S	S	S	S	S	S	S	T	X	X	X	X	X	X
SB05	C	C	C	C	V	V	V	V	S	S	S	S	S	T	X	X	X	X	X	X
SB06	C	C	V	V	V	V	V	V	S	S	S	S	S	T	X	X	X	X	X	X
SB07	C	C	C	C	C	C	C	C	S	S	S	S	S	T	X	X	X	X	X	X
SB08	C	C	C	C	C	C	S	S	S	S	S	S	S	T	X	X	X	X	X	X
SB09	C	C	C	C	C	C	C	C	V	V	V	V	V	V	V	V	S	S	S	T
SB10	C	C	C	C	C	C	V	V	V	V	V	V	V	V	S	S	S	S	S	T
SB11	C	C	C	C	C	C	C	C	C	C	C	C	C	C	V	V	V	V	S	T
SB12	C	C	C	C	C	C	C	C	C	C	V	V	V	V	S	S	S	S	S	T
SB13	C	C	C	C	C	C	C	C	V	V	V	V	V	V	S	S	S	S	S	T
SB14	C	C	C	C	C	C	V	V	V	V	V	V	V	S	S	S	S	S	T	
SB15	C	C	C	C	C	C	V	V	V	V	S	S	S	S	S	S	S	S	T	
SB16	C	C	C	C	V	V	V	V	S	S	S	S	S	S	S	S	S	S	T	
SB17	C	C	C	C	C	C	V	V	V	V	V	V	V	S	S	S	S	S	T	
SB18	C	C	C	C	V	V	V	V	V	V	V	V	S	S	S	S	S	S	T	
SB19	C	C	C	C	C	C	C	C	C	C	C	C	S	S	S	S	S	S	T	
SB20	C	C	C	C	C	C	C	C	S	S	S	S	S	S	S	S	S	S	T	
SB21	C	C	C	C	C	C	C	C	C	C	C	C	V	V	V	V	S	S	S	T
SB22	C	C	C	C	C	C	C	C	V	V	V	V	S	S	S	S	S	S	T	
SB23	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	S	T
SB24	C	C	C	C	C	C	C	C	C	C	C	C	S	S	S	S	S	S	T	
SB25	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	S	S	S	T
SB26	C	C	C	C	C	C	V	V	V	V	S	S	S	S	S	S	S	S	T	
SB27	C	C	C	C	C	C	V	V	V	V	S	S	S	S	S	S	S	S	T	

- C** CURRENT
- V** VOLTAGE
- S** SIGNAL/TRCP
- T** TEST SIGNAL
- X** NOT POPULATED
- SHORTING BRIDGE